

Code setting guide for iQ PLUS / iQ PLUS DUO




Selector switch Dog I / Dog II

1. Start with the receiver/collar turned off.
On the front of the transmitter there is a Selector Switch I - II. Set this selector switch on the "I" position to synchronize the transmitter with the first (or the only) receiver/collar. Set the selector switch on the "II" position to synchronize the transmitter with the second receiver/collar.



Intensity Selection Dial

2. Select the intensity level **0** with the intensity selection dial on top of the transmitter.



3. Place the red dot on the back of the transmitter against the red dot on the receiver/collar. Hold the two red dots together for several seconds, until the green LED on the receiver/collar starts to blink rapidly, and then separate the two red dots.



NICK button and CONSTANT button
on the front of the transmitter.

4. Hold the NICK button and the CONSTANT button on the front of the transmitter simultaneously down for 3 seconds or until the rapid green blink of the LED on the receiver/collar resumes a slower pace.
The code setting work is now completed.